



# Help Residents Thrive Using Echo

## Your Guide to Being a SerenitySmart™ Champion

As a valued team member at our SerenitySmart™ Community, you have the exciting opportunity to help residents gain independence through our voice-activated smart concierge. This technology makes their lives easier - and your job more rewarding!

### Make a Difference Every Day

#### Assist Residents to.....



#### Improve Safety and Wellness

Check in Daily (IL Only) or Call for Help



#### Be in the Loop

Check community announcements




#### Access Menus & Activities

See and hear information to plan their day



#### Stay Close to Family

Set up video calls to keep loved ones connected





# Serenity Echo Device Basics

## Resident Commands

All residents need to do is say "Echo..." followed by what they want. Your encouragement helps them gain confidence with these simple commands:

### Check-in for the day

"Check Me In"

### Find out the Menu

"What's for dinner?"

### Learn about today's Activities

"Activities for today"

### Find community announcements

"Read notifications"

### Create Personal Reminders

"Remind me to..."

### Video call Family

"Call my daughter Jane"

### Call for emergency help

"Call Help"

### Check the weather

"What's the weather forecast"

### Play music

"Play classical radio"

### Have fun

"Sing happy birthday"

### Contact specific staff

"Call Front Desk"

### Exit any screen

"Exit"

## Common Resident Questions

- "Is it always listening?" - No, only when the resident uses the wake word
- "Who can hear me?" - Only the device for processing commands
- "What can I ask it?" - Anything! (but refer to common commands above)
- "Can I move the device?" - Yes, but only within the unit it is assigned, simply unplug and move

## Basic Troubleshooting

- Device not connecting to wifi - Contact your Maintenance or IT Department
- No Response to "Echo" - Check for Red Light at top and press to turn off, or try "Alexa" instead
- Incorrect information displayed - Contact Serenity in your "Serenity Support" channel
- The device is "stuck" - Unplug for 30 seconds

